



OEM STYLE SIDE STEP BARS

(2007-2018 WRANGLER JK - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Driver Side Step
- (1) Passenger Side Step
- (2) Front Brackets
- (2) Middle Brackets
- (2) Rear Brackets
- (6) M8x1.25 x 20mm Bolts
- (6) M8 Flat Washers
- (18) M6x1.00 x 20mm Allen Bolts
- (36) M6 Flat Washers
- (18) M6 Nuts
- (1) Allen Key

TOOLS REQUIRED

- 10mm Socket/Wrench
- 13mm Socket/Wrench
- Ratchet

SKU # J132196



STEP 1

Place the side step on a soft surface. Align the (3) brackets to the side step until the brackets sit flush on the side step. Loosely secure each bracket to the side step using (3) M6x1.00 x 20mm Allen bolts and (3) M6 flat washers per bracket.

Note: The bracket with the shorter studs installs at the rear of the side step.



STEP 2

Align the side step bracket studs to the holes in the vehicle pinch weld. Secure the side steps to the pinch weld using (2) M6 nuts and (2) M6 flat washers per bracket.



STEP 3

Using (1) M8x1.25 x 20mm bolt and (1) M8 flat washer, secure the side step to the pre-drilled holes under the vehicle for each bracket.



STEP 4

Tighten all hardware evenly until secure. Repeat steps 1-3 to the opposite side.

Installation is now complete.