



HEADLIGHT TRIM & GRILLE INSERT KIT - MATTE BLACK

(2018+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Headlight Inserts
(7) Grille Inserts

TOOLS REQUIRED

Isopropyl Alcohol
Clean Microfiber Towel

SKU # J133780-JL

**STEP 1**

Prepare for the installation by thoroughly cleaning the grille and headlight buckets with automotive grade soap and water. Allow the grille and headlight buckets time to dry. Using isopropyl alcohol, wipe down the grille and headlight buckets to remove any remaining wax and grease. **Ensure the grille is completely dry. If it is not the inserts will not stick.

**STEP 2**

Test fit the headlight inserts. They are specific to each side. Before removing the tape backing determine which is which by rotating the inserts around for best fit. Once familiar with how the inserts fit, peel back the tape backing and install. Apply firm even pressure to the taped surface to ensure proper adhesion.

STEP 3



Test fit the grille inserts prior to removing the tape backing. Once familiar with the way the inserts fit, remove the tape backing and install. Apply firm even pressure over the taped surfaces to ensure proper adhesion.

STEP 4



Installation is not complete.