



DEAD PEDAL ASSEMBLY

(2018+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Upper Bracket
- (1) Dead Pedal Assembly
- (2) M6 Allen Bolts
- (2) M6 Lock Nuts

TOOLS REQUIRED

- 10, 13mm Socket
- Ratchet
- M4 Allen Key

SKU #



STEP 1

Using a 13mm socket, remove the nut on the fire wall just to the left of the brake pedal.



STEP 2

Using 10mm socket the provided M6 Allen head bolt and lock nut, bolt the dead pedal assembly to the upper bracket. This can be adjusted later.



STEP 3

Bolt the upper bracket to the fire wall using the factory 13mm nut. Adjust the pedal up or down as need for best comfort. Installation is now complete.