

MULTI-FUNCTION CLIP HOLDER

(2018+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Clip Assembly
- (2) Replacement Clips
- (1) Soft Pry Tool

TOOLS REQUIRED

10mm Socket and Ratchet



STEP 1



Using the provided soft pry tool, carefully pry the HVAC control panel away from the vehicle.



STEP 2

Using a 10mm Socket and ratchet, remove the 10mm bolt that hold the left side of the dash grab handle to the vehicle.



STEP 3

Gently pull the handle away from the dash and place the clip assembly between the handle and the dashboard. Re-install the 10mm bolt.



STEP 4

Ensure all the of clips are present on the HVAC panel, if any are missing replace them with the provided clips.





STEP 5

Press the HVAC panel back into the dashboard. Installation is now complete.