



---

# THREADED ARM REST COVER

(2018-2025+ WRANGLER JL)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Arm Rest Cover

### TOOLS REQUIRED

---

Isopropyl Alcohol

SKU # J133788-JL

## STEP 1



Prepare for the installation by thoroughly cleaning the vehicle armrest. A clean surface is crucial for the installation of the arm rest cover. Wipe the factory arm rest with isopropyl alcohol to remove any and all oil/grease contaminants.

## STEP 2



Test fit the arm rest cover prior to removing the double sided tape. It is important to stick the front of the cover on first (1) then lay the cover back onto the arm rest (2). Once you are comfortable with the installation, remove the double sided tape. Install the arm rest and apply firm even pressure to the taped surfaces to ensure proper adhesion.