



HARDTOP QUICK REMOVAL FASTENER KIT

(1997-2018 WRANGLER TJ & JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(8) Thumb Screws
(8) Washers
(8) Plate Nuts

TOOLS REQUIRED

T40 Torx Bit
Flat Screw Driver

SKU # J134455

STEP 1



Using a T40 Torx bit, remove the fasteners securing the top to the vehicle.

STEP 2



Remove the factory nut from the underside of the mounting rail.

STEP 3



Hold the new rail nut under the mounting location.

STEP 4



Place the thumb screw through the washer and thread it into the rail nut. Hold the rail nut to prevent it from spinning until the thumb screw starts to get tight. Repeat the process at each mounting location. Installation is now complete.