

TAILGATE STORAGE BAG

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Tailgate Mount
- (2) Accessory Bags
- (9) RivNuts
- (9) M6x1.0 25mm Allen Bolts
- (9) M6 Flat Washers

TOOLS REQUIRED

Masking Tape
Marker
Drill
11/32" Drill Bit
M6 Rivnut Tool
T-27 Torx Socket
Socket Wrench

4mm Allen Wrench





STEP 1

Begin by opening the tailgate and removing the tailgate hinge bolts using a T-27 Torx socket.



STEP 2

Position the tailgate mounting pad behind the tailgate hinge and install the factory bolts.





STEP 3

Using masking tape, hold the mounting pad against the tailgate.



STEP 4

Mark the hole locations. Drill the hole to 11/32" and install the rivnuts. Secure the mounting pad to the tailgate using the provided Allen bolts. Tighten with a 4mm Allen wrench. Then mount the storage bags as desired. Installation is now complete.