



COWL VENT AIR SCOOP

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Cowl Vent Scoop

TOOLS REQUIRED

Towel
Isopropyl Alcohol

SKU # J135780

STEP 1

Using automotive grade soap, wash the cowl area. Allow the cowl to thoroughly dry. Wipe the paint with isopropyl alcohol to ensure the cleanest possible surface. A clean dry surface is crucial.

STEP 2

Test fit the cowl scoop prior to removing the tape backing. Then peel back the red tape backing. Carefully center the scoop over the cowl. Apply firm even pressure over the taped surfaces to ensure proper adhesion. Installation is now complete.