

REDROCK^{4x4}

Door Hanger Brackets (TJ, JK, JL)

Contents:

(2) Door Hanger Brackets

Required:

(4) 3/8" x 3" Lag Bolts

Drill

15/64" Drill Bit

9/16" Wrench



-Minimum of (2) 3/8" x 3" long lag bolts are required for installation of each door bracket. These can be found at any local hardware store.

-Locate a suitable mounting location. Door brackets **must** be screwed into solid wood studs. Failure to do so will result in damage to the doors.

-Drill a 15/64" pilot hole into the mounting studs.

-Tighten the door brackets using a 9/16" wrench.

SKU: J135787