



SMOKED LED THIRD BRAKE LIGHT

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LED Third Brake Light

TOOLS REQUIRED

T-20 Torx Driver

SKU # J135790

STEP 1



Begin by removing the (4) screws that hold the factory third brake light to the tire carrier. Unplug the wiring harness from the third brake light and remove the third brake light from the vehicle.

STEP 2



Plug the third brake light harness into the LED brake light.



STEP 3

Install the brake light to the tire carrier using the (4) Factory Screws. Installation is now complete.