

Installation Instructions for RedRock4X4 Cold Air Intake (Wrangler 3.8L)

TOOLS REQUIRED:

10mm socket
8mm socket
Flathead Screwdriver
Allen Key Set

Step 1:

Unplug your factory IAT sensor located on the side of the intake tube.



Step 2:

Slide the PCV hose off of the factory air hose.



Step 3:

Using a flathead screwdriver, remove the hose clamp holding the intake tube to the throttle body.



Step 4:

Pull the entire intake assembly up and away from the vehicle.



Step 5:

Remove your factory IAT sensor from the factory intake tube.



Step 6:
Install the IAT sensor into the new intake tube assembly.



Step 9:
Install the heat shield using the factory mounting positions and secure with bolts.



Step 7:
Using the (6) supplied nuts and screws, assemble the new heat shield as shown.



Step 10:
Add the supplied rubber gaskets to the top of the heat shield and in hole for the intake.



Step 8:
Remove the 8mm screw holding the fan shroud to the radiator.



Step 11:
Install the intake tube onto the coupler and onto the factory throttle body.



Step 12:
Secure the intake tube to the heat shield using the supplied spacer.



Step 15:
Install the filter and tighten down using the supplied hose clamp.



Step 13:
Reinstall the factory PCV hose onto the new intake tube and secure with new clamp.



Step 14:
Plug in the IAT sensor that you previously installed into the intake tube.

