



HYPER FLASH LED THIRD BRAKE LIGHT

(2007-18 Wrangler JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Hyper Flash Third Brake
Light

TOOLS REQUIRED

T-20 Torx Driver

SKU# J137870 / J137871

STEP 1



Begin by removing the (4) screws that hold the factory third brake light to the tire carrier. Unplug the wiring harness from the third brake light and remove the third brake light from the vehicle.

STEP 2



Plug the third brake light harness into the LED brake light.



STEP 3

Install the brake light to the tire carrier using the (4) Factory Screws. Installation is now complete.