



AUXILIARY BRAKE LIGHT

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Brake Light

TOOLS REQUIRED

Lug Socket
T20 Torx Bit
Torque Wrench

SKU # J138959

**STEP 1**

Using a lug wrench, remove the (3) lug nuts securing the spare tire to the tailgate. Remove the tire from the vehicle.

**STEP 2**

Using a T20 Torx bit, remove the (4) screws securing the factory third brake light to the tire carrier.

**STEP 3**

Depress the tab on the electrical connection. Pull the plug away from the light.

**STEP 4**

JK - Plug the new LED wiring harness into the factory plug. Test the light prior to reinstalling the spare tire.

STEP 5

Ensure the brake light bracket is flush against the spare tire mount. Do not pinch the wires between the bracket and the spare mount.

STEP 6

Reinstall the spare tire using the factory lug nuts. Follow the factory torque specs found in your owners manual. Installation is now complete.