


INSTALLATION INSTRUCTIONS

PART No.

FB21098

**All Jeep® Models
Fairlead License Plate Mount**



REQUIRED TOOLS

14mm Socket
10mm Socket
4mm Allen

KIT CONTAINS

Fairlead License Plate Mount
M6 Nylon Plastic Washer
M6 – 1.0 SS Nyloc Nut
M6 SS Washer 12mm OD
M6 SS Lock Washer
M6 – 1.0 x 20mm SS Button Head Bolt
M6 – 1.0 SS Hex Nut
M6 – 1.0 x 16mm SS Button Head Bolt

QTY

1
6
2
8
4
4
4
4
2

**<< Please use caution or remove the Fairlead License Plate Mount >>
<< before entering a car wash that uses brushes. We recommend brushless car washes. >>**

All Jeep® Models Fairlead License Plate Mount

1) PREPARE FOR INSTALL

Loosen your fairlead and any other accessories from the front of your bumper.



They should wiggle freely without falling off.

2) INSERT FAIRLEAD LICENSE PLATE MOUNT

Slide your Plate Mount in between your fairlead and bumper or any other accessory.




It should rest on top of each bolt.

Next resecure the fairlead mounting bolts.



3) INSTALL YOUR LICENSE PLATE

Hold your license plate up to the 'X' bracket and loosely secure it with the included bolts, washers, lock washers, and nuts.



Secure each bolt with a 10mm socket and 4mm allen key.






INSTALLATION INSTRUCTIONS

PART No.

FB21098

**All Jeep® Models
Fairlead License Plate Mount**

Lastly resecure any other accessories previously loosened or uninstalled including winch cable and hook.



**ENJOY YOUR NEW FISHBONE OFFROAD FAIRLEAD
LICENSE PLATE MOUNT!!!**