



# ALUMINUM FRONT GRAB HANDLES

(2007-2018 Wrangler JK)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) Driver's Side Handle
- (1) Passenger's Side Handle
- (2) 70mm Allen Bolts
- (2) 100mm Allen Bolts
- (2) Large Spacers
- (2) Small Spacers

### TOOLS REQUIRED

---

- 13mm Socket
- 5mm Allen Key/Socket
- Ratchet

SKU # J139329

**STEP 1**



Remove (2) 13mm bolts from the vehicle.

**STEP 2**



Using (1) 100mm bolt and (1) large spacer, insert the bolt through the handle, and insert the spacer over the bolt. Thread into the body but do not tighten.



**STEP 3**

Insert the (1) 70mm bolt and (1) small spacer into the handle, then thread the bolt into the vehicle.



**STEP 4**

Tighten the (2) bolts evenly. Repeat procedure on opposite side.

Installation is now complete.