



REAR ALUMINUM GRAB HANDLES

(2007-2018 WRANGLER JK 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Driver's Side Grab Handle
- (1) Passenger's Side Grab Handle
- (4) Grab Handle Spacers
- (4) M6x65mm Allen Bolts

TOOLS REQUIRED

- 5mm Allen Key/Socket
- 10mm Socket
- Ratchet

SKU # J139330



STEP 1

Remove (2) 10mm bolts from the roll bar.



STEP 2

Using (2) M6x65mm Allen bolts and (2) Grab Bar Spacers, align the spacers with the grab bar into the bolt holes and thread the bolt into the roll bar.



STEP 3

Tighten the (2) Allen bolts evenly using a 5mm Allen Key/Socket. Do not over tighten to prevent bolt/thread damage. Repeat procedure for opposite side.

Installation is now complete.