



HYPER FLASH LED THIRD BRAKE LIGHT

(2018+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Hyper Flash 3rd Brake Light
- (2) Screws

TOOLS REQUIRED

- T25 Torx Socket
- Socket Wrench
- Phillips Head Screwdriver

STEP 1



With the spare tire removed, use a T25 Torx bit to remove the 3rd brake light assembly from the factory tire carrier. Remove the (11) Torx screws and remove the cover from the tire carrier assembly.

STEP 2



Using a T25 Torx bit remove the (2) screws securing the brake light to the assembly. Unplug the 3rd brake light from the light harness and remove the light from the assembly. Install the hyper flash brake light using the provided screws. Reinstall in reverse order.