

LIMB RISERS

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

- (2) Limb Riser Cables
- (2) Windshield Frame Brackets
- (2) Hood Latch Brackets
- (2) M8x20mm Tapered Bolts
- (2) M8 Flat Washers
- (2) M8 Lock Nuts
- (6) Rivets

TOOLS REQUIRED

10mm Socket

5mm Allen Socket

Socket Wrench

10mm Wrench

13mm Wrench

Rivet Gun

Drill

9/64 Drill Bit

Permanent Marker





Open the hood on the vehicle. Remove (2) 10mm nuts to remove the hood latch from the vehicle.



STEP 2

Place the hood mounting bracket onto the hood latch location, then reinstall the hood latch to the vehicle reusing original hardware. Be sure the mounting bracket is in the correct orientation for proper fit.





STEP 3

Using the windshield frame bracket as a template, mark the (3) holes in the bracket for drilling into the windshield frame. Drill the holes using a 9/64th drill bit. Using a rivet gun and provided (3) rivets, secure the windshield frame bracket to the vehicle.



STEP 4

Attach the limb riser cable to the hood mounting bracket. Place the cable around the bracket. Install the pin and clip to secure the cable to the bracket.





STEP 5

Choose the appropriate mounting location for the limb riser cable. Install the limb riser cable to the windshield mounting bracket using (1) M8x20mm Allen bolt, (1) M8 flat washer, and (1) M8 locking nut. Tighten until secure.



STEP 6

Adjust the tension rods evenly to the desired tension. Tighten the jam nuts using a 10mm wrench. Repeat steps 1-5 on the opposite side.

Installation is now complete.