



WATER RESISTANT CAB COVER

(1987-2006 WRANGLER YJ & TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Cab Cover

TOOLS REQUIRED

Exterior Detailer

SKU # J141590

STEP 1



Clean the exterior of the vehicle to prevent vehicle scratches.

STEP 2



Drape the cab cover over the vehicle, making sure the mirror flaps are towards the front of the vehicle.



STEP 3



Pull the cab cover over the entire cab. Pull the sides over the mirrors and down the doors. Make sure the cab cover is even on all sides.

STEP 4



Using the (6) attached elastic hooks, attach the cover to the frame of the vehicle.

Installation is now complete.