



PRECISION MOLDED CARGO LINER

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Cargo Liner

TOOLS REQUIRED

Vacuum Cleaner

SKU # J150090

STEP 1



Clean the vehicle cargo area with a vacuum cleaner remove dirt/debris.

STEP 2



Identify the front/rear of the cargo liner, and place the liner into the vehicle cargo area.

Note: If the cargo liner does not rest flat, place the liner in the sun before or after installation. Cut the anchor holes in the liner, if desired.

Installation is now complete.