



HOOD MOUNTED MIRROR KIT

(2018-2021 WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Mirror
- (1) Mounting Bracket
- (1) Mirror Arm
- (2) M6 Bolts
- (2) M6 Locking Nuts
- (1) Allen Key

TOOLS REQUIRED

- 8mm, 10mm Wrench
- 10mm Socket
- Ratchet
- Phillips Screwdriver
- Exterior Detailer

SKU # J150588

STEP 1

Install the mirror to the mirror arm. Thread the mirror onto the mirror arm, then use the hardware attached to the mirror to lock the mirror into place.

STEP 2

Secure the mounting bracket to the mirror arm using the provided (2) M6 bolts and (2) M6 flat washers.

Note: Depending on the side of the vehicle the mirror will mount on, the mirror arm will vary in orientation on the mounting bracket.



STEP 3

Remove (2) 10mm nuts from the hood latch bolted to the hood. Remove the hood latch from the vehicle.



STEP 4

Insert the mounting bracket in between the hood latch and the hood. Re-secure the hood latch to the vehicle reusing original hardware. Tighten until secure.



STEP 5

Lower the hood of the vehicle. Set the mirror to the appropriate adjustment. Tighten the (3) Phillips screws on the back of the mirror to lock the mirror into adjustment.



STEP 6

Installation is now complete.