

# DETACHABLE TRAIL MIRRORS

(1997-2006 WRANGLER TJ) (2007-2018 WRANGLER JK)

### INSTALLATION INSTRUCTIONS

### **CONTENTS**

- (2) Mirrors
- (2) Mounting Arms
- (2) Mounting Brackets
- (2) Twist Knobs
- (2) Clamp Sleeves
- (4) T-40 Torx Bolts
- (4) Flat Washers
- (4) Nylon Washers

# **TOOLS REQUIRED**

T-40 Torx Socket 10mm Socket Ratchet Phillips Screwdriver





# STEP 1

Remove (2) T-40 Torx bolts from the vehicle. Place (1) mounting bracket to the vehicle and re-install the original (2) T-40 Torx bolts.

Note: TJ will replace original hardware and use provided (2) T-40 Torx bolts, (2) Nylon Flat Washers, and (2) Flat Washers.



### STEP 2

Install (1) clamping sleeve onto the mirror mounting arm, then insert the mounting arm into the mounting bracket. Tighten into place using (1) twist knob.





# STEP 3

Secure the mirror assembly to the vehicle using (1) M6 nut, (1) M6 lock washer, and (1) M6 flat washer. Tighten until secure.



# STEP 4

Loosen the (3) Phillips head screws to adjust mirror. Once adjusted, tighten the (3) Phillips screws to lock into place. Repeat steps 1-4 to the opposite side.

Installation is now complete.