



DETACHABLE TRAIL MIRRORS

(1997-2006 WRANGLER TJ)
(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Mirrors
(2) Mounting Arms
(2) Mounting Brackets
(2) Twist Knobs
(2) Clamp Sleeves
(4) T-40 Torx Bolts
(4) Flat Washers
(4) Nylon Washers

TOOLS REQUIRED

T-40 Torx Socket
10mm Socket
Ratchet
Phillips Screwdriver

SKU# J154609

STEP 1

Remove (2) T-40 Torx bolts from the vehicle. Place (1) mounting bracket to the vehicle and re-install the original (2) T-40 Torx bolts.

Note: TJ will replace original hardware and use provided (2) T-40 Torx bolts, (2) Nylon Flat Washers, and (2) Flat Washers.

STEP 2

Install (1) clamping sleeve onto the mirror mounting arm, then insert the mounting arm into the mounting bracket. Tighten into place using (1) twist knob.



STEP 3

Secure the mirror assembly to the vehicle using (1) M6 nut, (1) M6 lock washer, and (1) M6 flat washer. Tighten until secure.



STEP 4

Loosen the (3) Phillips head screws to adjust mirror. Once adjusted, tighten the (3) Phillips screws to lock into place. Repeat steps 1-4 to the opposite side.

Installation is now complete.