



OFF-ROAD TRAIL MIRRORS

(1997-2021 WRANGLER TJ, JK, & JL)
(2020-2021 GLADIATOR JT)

INSTALLATION INSTRUCTIONS

CONTENTS

- (2) Rectangle Mirrors
- (2) Right Angle Mirror Brackets
- (2) Straight Mirror Brackets
- (2) M10 Nuts
- (1) M10 Locking Nut
- (2) M10 Lock Washer
- (1) M10 Flat Washer

TOOLS REQUIRED

- 14mm Socket/Wrench
- Ratchet
- Phillips Screwdriver

SKU # J154610

STEP 1



Remove the door from the vehicle following procedures in the vehicle owners manual.

Assemble (1) right angle bracket and (1) straight bracket together using (1) M10 nut and (1) M10 lock washer. Tighten until secure.

STEP 2



Place the threaded portion of the bracket through the vehicle door hinge. Install (1) M10 locking nut at the bottom of the mirror bracket to secure the mirror brackets to the vehicle. Tighten until secure.



STEP 3

Install the mirror to the mirror assembly brackets using (1) M10 flat washer, (1) M10 lock washer, and (1) M10 nut. Tighten until secure.



STEP 4

Adjust the mirror to the desired position, then tighten the (3) Phillips head screws to lock the mirror into place.

Installation is now complete.