



Required Tools (Not included)	
Qty.	Description
1	1/2" Socket
1	Extension to ratchet
1	Ratchet

Product Image	
1	
2	

- 1.- Before beginning the installation, please read all directions carefully and verify that all necessary hardware is accounted for. If any parts are missing, stop the installation and contact your distributor immediately.
- 2.- To maintain and care this product keep it clean and do not use abrasive cleaners or polish waxes. We recommend to use only non-abrasive automotive wax such as pure carnauba to avoid scratches and rust.
- 3.- Once the main brackets are installed (**sold separately**), the approximate installation time is 15 min.
- 4.- Place the U brackets inside the Running Board. Move them to align to the main brackets. **See illustration 1.**
- 5.- Place the 5/16" flat and lock washers with the 5/16 x1" hex head bolts. This hardware kit is included on the main brackets that are (**sold separately**). **See illustration 1.**
- 6.- Align the Running board and tighten the bolts using a 1/2" wrench.
- 7.- Periodically check your product because it may need a re-tighten of bolts.
- 8.- Fill the warranty card and place it inside your vehicle's glove box.

Diagram illustrating the installation of the main bracket and hardware kit onto the rail. The main bracket (sold separately) is shown being attached to the rail using the hardware kit (included in the hardware brackets). The hardware kit includes screws and washers. The diagram shows the bracket being positioned on the rail, with the hardware kit components being used to secure it. A curved arrow indicates the bracket's position relative to the rail. A label '1' points to the rail, and a label '2' points to the bracket. A label 'Main bracket (Sold separately)' points to the bracket, and a label 'Hardware kit (Included in the hardware brackets)' points to the hardware components.

Required Tools (Not included)	
Qty.	Description
1	1/2" Socket
1	Extension to ratchet
1	Ratchet

Product Image	
1	
2	

- 1.- Before beginning the installation, please read all directions carefully and verify that all necessary hardware is accounted for. If any parts are missing, stop the installation and contact your distributor immediately.
- 2.- To maintain and care this product keep it clean and do not use abrasive cleaners or polish waxes. We recommend to use only non-abrasive automotive wax such as pure carnauba to avoid scratches and rust.
- 3.- Once the main brackets are installed (**sold separately**), the approximate installation time is 15 min.
- 4.- Place the U brackets inside the Running Board. Move them to align to the main brackets. **See illustration 1.**
- 5.- Place the 5/16" flat and lock washers with the 5/16 x1" hex head bolts. This hardware kit is included on the main brackets that are (**sold separately**). **See illustration 1.**
- 6.- Align the Running board and tighten the bolts using a 1/2" wrench.
- 7.- Periodically check your product because it may need a re-tighten of bolts.
- 8.- Fill the warranty card and place it inside your vehicle's glove box.

Diagram illustrating the installation of the main bracket and hardware kit onto the rail. The main bracket (sold separately) is shown being attached to the rail using the hardware kit (included in the hardware brackets). The hardware kit includes screws and washers. The diagram shows the bracket being positioned on the rail, with the hardware kit components being used to secure it. A curved arrow indicates the bracket's position relative to the rail. A label '1' points to the rail, and a label '2' points to the bracket. A label 'Main bracket (Sold separately)' points to the bracket, and a label 'Hardware kit (Included in the hardware brackets)' points to the hardware components.