



# TRAIL SERIES PREMIUM REAR SHOCK ABSORBER FOR 3.5" - 4" LIFT

(1997-2006 WRANGLER TJ)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Shock Absorber

### TOOLS REQUIRED

---

1/2" Socket  
Ratchet  
17mm Wrench

SKU # J156695



**STEP 1**

Lift and support the vehicle using a floor jack and jack stands. Remove the vehicle wheels.

Locate the shock absorber, and remove the (2) bolts securing the shock to the frame.



**STEP 2**

Remove the (1) bolt securing the shock absorber to the axle. Remove the shock absorber from the vehicle.



---

**STEP 3**

Fit the new shock absorber between the axle mount and the vehicle frame.

Secure the top and the bottom of the shock to the vehicle using the OEM shock absorber bolts.

Installation is now complete.