



PRECISION MOLDED CARGO LINER

(2011-2018 WRANGLER JK - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Cargo Liner

TOOLS REQUIRED

Razor Knife

SKU # J156990



STEP 1



Subwoofer Equipped Vehicles: Using a razor knife, carefully cut the designated area to allow cargo liner to fit around the subwoofer assembly.

STEP 2



Place the cargo liner into the vehicle, ensuring the liner is as far into the cargo area as possible.

Installation is now complete.