



OEM STYLE SIDE STEPS

(2001-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Pair of Side Steps
- (2) Short Brackets
- (2) Long Brackets
- (4) U-Bolts
- (4) M8x1.25 Flange Nuts
- (8) M6 Flange Bolts
- (8) M6 Washers.

TOOLS REQUIRED

- 10, 14mm Socket
- Socket Wrench

SKU # J158308

**STEP 1**

Begin by threading the supplied u-bolts through the frame. Insert the shorter side of the u-bolt and loop it into the other hole.

**STEP 2**

****Note:** The shorter of the two brackets is the rear bracket. Carefully install the mounting bracket onto the u-bolts. Loosely thread on the supplied flange nuts to prevent accidentally pushing the u-bolts into the frame. Hook the tabs on the bracket into the slots in the frame. Then tighten down the u-bolts evenly.

STEP 3



Using the provided M6 hardware, bolt the side step to the brackets. Loosely install all hardware prior to fully tightening. Once everything is aligned, tighten the bolts.

STEP 4



Installation is now complete.