



HD FUEL DOOR

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) FUEL DOOR
(4) SCREWS

TOOLS REQUIRED

TRIM PANEL REMOVAL TOOL
DRILL
1/8" DRILL BIT
MARKER

SKU # J163061

STEP 1

Start by turning the gas cap counter-clockwise to remove from the filler neck.

STEP 2

Using a trim panel removal tool, carefully pry around the edges of the factory fuel bezel to release the clips securing it in place. Then pry the rubber gasket around the filler neck and pull away removing the bezel from the vehicle.

STEP 3

Line up the new fuel door with the factory fuel cover bezel and mark the (4) holes. Make sure the new fuel door is centered, and then drill the (4) 1/8" holes.

STEP 4

Once the (4) holes are drilled, secure the new fuel door to the bezel using a Phillips head screw driver with the supplied (4) screws.



STEP 5

Reinstall the bezel with the fuel door to the body of the vehicle by applying firm pressure. This will click into place. Then secure the rubber gasket around the fuel filler neck. Installation is now complete.