



IN-CHANNEL WINDOW DEFLECTORS

(2018-2025+ WRANGLER JL - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Deflector
- (1) RH Front Deflector
- (1) LH Rear Deflector
- (1) RH Rear Deflector

TOOLS REQUIRED

N/A





STEP 1

Lower the window down to the lowest point. Insert the upper portion of the window deflector into the vehicle window channel.



STEP 2

Press the front portion of the window deflector into the window channel, ensuring the entire window deflector is inside the window channel excluding the lower corner. Raise the window up entirely to lock the window deflector into place.

Repeat steps 1-2 to the remaining window deflectors. Installation is now complete.