



HARD TOP CLAMP ASSEMBLY

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Hard Top Clamp Assembly

TOOLS REQUIRED

T-30 Torx Socket/Bit
Ratchet

STEP 1

Remove hard top panel from the vehicle. Remove the (3) T-30 Torx screws from the original hard top latch assembly.

Note: Hardware will be reused.

STEP 2

Place and secure the new hard top latch to the panel using the original hardware. Tighten until secure. Reinstall the hard top panel to the vehicle.

Installation is now complete.