



TURN SIGNAL TRIM

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Turn Signal Trim

TOOLS REQUIRED

Isopropyl Alcohol
Microfiber Cloth



STEP 1

Clean the turn signal lens using isopropyl alcohol.



STEP 2

Peel the red double sided tape backing from the turn signal trim. Align and adhere the turn signal trim to the turn signal lens.

Repeat steps 1-2 to the opposite side of the vehicle. Installation is now complete.