



# CHROME GRILLE INSERTS

(1997-2006 WRANGLER TJ)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(7) Chrome Grille Inserts

### TOOLS REQUIRED

---

Exterior Detailer  
Microfiber Cloth



**STEP 1**

Clean and dry the grille of the vehicle using exterior detailer and a microfiber cloth.



**STEP 2**

Place the grille insert into the bottom portion of the grille. Hinge the top portion towards the grille and press firmly into the grille to secure into place.

Repeat this step for all grille inserts.



---

**STEP 3**

Installation is now complete.