



DASHBOARD CB MOUNT

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Dashboard CB Mount
- (2) M6x1.00 x 20mm Allen Bolts
- (2) M6 Lock Washers
- (4) M6 Flat Washers
- (2) M6 Lock Nuts

TOOLS REQUIRED

- Phillips Screwdriver
- 4mm Allen Key (Optional)
- 10mm Wrench (Optional)

**STEP 1**

Remove (2) screws from the speaker cover on the dashboard.

**STEP 2**

Align the CB mount to the dashboard and install the original (2) Phillips screws through the mount and into the dashboard at the original locations.

Note: CB mount can be installed at (2) height options. Install the screws at the desired height. Use the included M6 hardware in the remaining holes to reinforce the mount, if necessary.

Installation is now complete.