



# OVERHEAD MOLLE PANEL

(2018+ WRANGLER JL - 4 DOOR)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) Overhead Molle Panel
- (1) LH Mounting Bracket
- (1) RH Mounting Bracket
- (4) M8x1.25 x 80mm Allen Bolts
- (4) M8 Lock Washers
- (4) M8 Flat Washers
- (4) M8 Flange Nuts
- (4) M6x1.00 x 15mm Allen Bolts
- (4) M6 Lock Washers
- (4) M6 Flat Washers

### TOOLS REQUIRED

---

- 4mm, 5mm Allen Keys/Sockets
- 15mm Wrench
- Ratchet

SKU # J166732-JL  
Edited: 01/25/2022

**STEP 1**

Open the rear seating door and locate the (2) bolt holes in the roll bar. Using the appropriate mounting bracket, secure the mounting bracket to the roll bar using (2) M8 x 80mm Allen bolts, (2) M8 lock washers, (2) M8 flat washers, and (2) M8 flange nuts. Do not fully tighten the hardware for later adjustments.

Repeat this step for the opposite side of the vehicle.

**STEP 2**

Lift the molle panel over the previously installed mounting brackets. Align the welded on M6 nuts towards the bolt holes in the mounting brackets. Secure the molle panel to the brackets using (2) M6 x 15mm bolts, (2) M6 lock washers, and (2) M6 flat washers per side. Tighten all hardware to secure the molle panel into place.

Installation is now complete.