



# MIRROR MOUNT KIT

(1997-2006 WRANGLER TJ)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Mirror Mount
- (1) RH Mirror Mount
- (6) M6 Allen Bolts
- (6) M6 Lock Nuts

### TOOLS REQUIRED

---

- T-27 Torx Screwdriver/Socket
- T-40 Torx Screwdriver/Socket
- 4mm Allen Key/Socket
- Ratchet
- 10mm Wrench



**STEP 1**

Remove (2) T-40 Torx bolts from the windshield hinge trim.



**STEP 2**

Install the mirror mount bracket to the vehicle reusing the original (2) T-40 Torx bolts. Tighten until secure.

**STEP 3**

Remove (3) T-27 Torx bolts to remove the mirror assembly from the door.

Note: Hardware will not be reused.

**STEP 4**

Secure the mirror assembly to the mounting bracket using the provided (3) M6 Allen bolts and (3) M6 lock nuts. Tighten until secure.

Repeat steps 1-4 to the opposite side of the vehicle. Installation is now complete.