

CONSOLE SIDE STORAGE

(2018+ WRANGLER JL) (2020+ GLADIATOR JT)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Storage Bin

TOOLS REQUIRED

Isopropyl Alcohol Microfiber Cloth





STEP 1

Open the center console lid. Test fit the storage bin by aligning the upper mounts to the posts on the center console. Once familiar with fitment, remove the panel clean the center console to prepare for double sided tape using isopropyl alcohol and a microfiber cloth.



STEP 2

With the tape backing peeled off, re-install the storage bin and firmly apply pressure to adhere the double sided tape to the center console. Once adhered, close the center console lid.

Installation is now complete.