



INSTALLATION INSTRUCTIONS

Jeep Wrangler Sound Deadening Headliner

PART #'s 050132, 050134, 050136, 050156, 050158
3 Piece kit plus 11 filler strips:
 A. 2 - 2" X 24"
 B. 2 - 2" X 25"
 C. 2 - 2" X 38"
 D. 5 - 2" X 39"

PART #'s 050137, 050139, 050141, 050159, 050161
4 Piece kit plus 18 filler strips:
 A. 2 - 15" X 1.625"
 B. 5 - 16" X 1.625"
 C. 5 - 18.5" X 1.625"
 D. 2 - 19" X 1.625"
 E. 4 - 21" X 1.625"

NOTES: This kit is designed to fit Jeep Wranglers equipped with factory hardtops. One person can install the front panels over the driver and passenger seats (JK Models). However, it is recommended that a minimum of 2 people install the panels on the back part of the hardtop, as they are large (JK & TJ Models). We suggest you remove the hardtop from vehicle and place on the floor in an inverted position. Placing the hardtop on a blanket is recommended to protect it from scratches. Lay the parts in place with the paper release liner left in place to note its position and where it will be installed. Once the adhesive contacts a clean surface, it is extremely difficult to remove the adhesive. Be sure the part is in the desired position before adhering it!

PART #'s 050138, 050140, 050142, 050160, 050162
4 Piece kit plus 10 filler strips:
 A. 2 - 22.25" X 1.625"
 B. 2 - 21.75" X 1.625"
 C. 2 - 24" X 1.625"
 D. 2 - 25" X 1.625"
 E. 2 - 30.25" X 1.625"

PART #'s 050143, 050144, 050145
2 Piece kit plus 6 filler strips:
 A. 2 - 4" X 58"
 B. 4 - 8" X 58"

PART #'s 050131, 050133, 050135, 050155, 050157
4 Piece kit plus 18 filler strips:
 A. 2 - 2" X 16" E. 2 - 2" X 24"
 B. 5 - 2" X 19" F. 2 - 2" X 25"
 C. 2 - 2" X 21"
 D. 5 - 2" X 22"

PART #'s 050146, 050147, 050148
2 Piece kit plus 6 filler strips:
 A. 2 - 4" X 58"
 B. 4 - 8" X 58"

TOOLS:
 Use manufacturer's suggested tools for hardtop removal.

SURFACE PREP:
 Vacuum or wipe down installation area to remove all loose debris/dust. Then clean with isopropyl alcohol to remove any contaminants.

1.) Remove the hardtop from vehicle following the manufacturer's suggested removal. Placing the hardtop on a blanket is recommended to protect it from scratches. Make sure to place the hardtop on the blanket in an inverted position.




Figure 1



Figure 2

Figure 1 – Hardtop removed and inverted (4 Door Shown) 2007 & Up

Figure 2 – Hardtop removed and inverted 1997-2006

2.) Once the hardtop is removed, clean the inside surface of the hardtop with isopropyl alcohol. This will ensure a good adhesive bond between the headliner and the hardtop.

*Note: The adhesive will not stick properly to a dirty surface.

3.) Install the foam "filler strips" in the molded ribs to ensure a smooth installation of the headliner. Without the "filler strips", the headliner will conform to the ridges in the top leaving an uneven appearance. Make sure to test fit the filler strips into the ribs of corresponding length before peeling the release liner on the strips.



Figure 3. Center part from one side

4.) Remove the paper release liner from the back of the part about to be installed. Once the liner is removed, center one side as shown in Figure 3.



Figure 4. Lay panel in place by applying gentle pressure

5.) Once the starting edge is adhered, lay down the rest of the part by applying gentle pressure by hand as shown in Figure 4.




Figure 5. Apply pressure by hand

6.) Once the parts have been installed, apply pressure by hand.




Figure 6

7.) Once all parts are installed, allow parts to sit in the top inverted for 25 minutes. (See Figures 6 and 7). This will allow the adhesive to set properly. Once the parts have set, you are ready to install the top back on your Jeep.

Figure 6 – Hardtop removed and inverted with headliner installed. (4 Door Shown) 2007 & Up

Figure 7 – Hardtop removed and inverted with headliner installed. 1997-2006




Figure 7

8.) Reinstall the hardtop according to the manufacturer's suggested installation.

NOTE: 2003 TO 2006 TJ models with factory speaker pods will have cutouts to fit around pods. (not shown)





www.BoomMat.com
800-264-9472

2011-2018 Jeep JK 4-Door Filler Strip placement

DRIVER SIDE

PASSENGER SIDE


REMOVABLE FRONT TOPS



2ND ROW SEATS



CARGO AREA



Boom Mat & Boom Mat XL

- Eliminate unwanted engine & road noise
- Enhance audio performance
- Dampen vibrations
- Easy peel & stick application
- 2MM thick Boom Mat & 4MM Boom Mat XL




Boom Mat Spray

- Spray application for hard to reach areas
- Eliminate unwanted engine & road noise
- Dampen vibrations
- Spray multiple coats for desired thickness




Under Carpet (UC)

- Perfect to use over Boom Mat
- Insulate your interior from heat & cold
- Provide additional sound deadening
- 3/8" thick




Heat Moldable Barrier

- Flexible .5lb/ft2 sound barrier
- Installs with scissors and a heat gun
- Sound and moisture barrier
- Perfect to use behind door panels
- 1/6" thick




Leather Look Sound Barrier

- Embossed leather grain
- Finishing touch for your interior
- Insulate interior from unwanted heat & noise
- Moisture resistant
- 5/16" thick




Under Carpet Lite (UC Lite)

- Multi-layered waterproof composite material
- Lightweight
- Superior heat & noise barrier
- Perfect to use over Boom Mat
- 1/2" thick



Floor & Tunnel Shield II (FT II)

- Peel & stick application
- Withstands 1750° F direct continuous heat
- Use to shield & reflect unwanted heat
- 3/16" thick



EXHAUST WRAP



PLUG BOOT & WIRE PROTECTION



LINE & HOSE SLEEVING



HEAT BARRIERS



TURBO SHIELDS

