



DASH PHONE HOLDER

(2011-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Storage Tray
- (1) Allen Bolt
- (1) Lock Nut
- (1) Phone Clamp
- (1) Mounting Arm
- (1) Allen Key

TOOLS REQUIRED

- 1/4" Socket
- Ratchet

SKU # J169181



STEP 1

Assemble the mounting arm to the storage tray using (1) Allen bolt and (1) lock nut. Place the lock nut in the insert under the tray, and secure the arm into place, tighten until secure.



STEP 2

Remove (1) 1/4" bolt from the dashboard storage area.



STEP 3

Align the phone holder tray to the vehicle dashboard, and secure into place using the original (1) 1/4" bolt, tighten until secure.



STEP 4

Secure the phone clamp to the mounting arm, using the attached nut to tighten around the arm pivoting ball.



STEP 5

Installation is now complete.