



Thank you for your business

Use supplied nuts and bolts to install the adapter to PSD. This adaptor will only work on a PSD pattern sold by Orange Boxx Fabrication.

1. Assemble the Adaptor so that the middle section of the hex hole is facing the PSD.
2. Make sure the nuts are in Hex holes before attaching to PSD.

If you have any questions contact us. sales@orangeboxxfab.com

Our hours are Monday - Friday 9am - 5pm eastern

Call us (336)804-0571

Tag us on Instagram

#orangeboxxfab