



Thank you for your business

Recon

1. Place the recon rack to your PSD System rack. What you are doing is figuring out which 3 holes

you want to attach your Recon to your PSD rack.

2. Mark holes you want to use.

3. Place supplied bolt with washer through the PSD Rack system. Add the supplied spacer. Tighten

supplied nut. Repeat for 2 other spots.

4. Place Recon rack over 3 Bolt/Spacer areas. Use supplied 3 prong thumb screws to attach to

your PSD rack System.

Overlander

1. This unit was redesigned. It does not need 4 bolts to hold it on. only 2 is Supplied with each

kit.

2. Without bolts you can place the Overlander anywhere you want to place it on the PSD rack

system. With bolts you must align holes to the PSD Rack system.

3. Use with bolts: Align Overlander with any 2 holes on PSD Rack System. Use 2 supplied bolts

with thumb screws to hold to the PSD Rack System.

Velcro Held PSD racks

1. Place the rack in the opening.

2. Use supplied Velcro to strap the rack to the opening.

If you have any questions contact us. sales@orangeboxxfab.com

Our hours are Monday - Friday 9am - 5pm eastern

Call us (336)804-0571