

4" LED FOG LIGHTS

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

- (2) LED Fog Lights
- (2) Wiring Harness Adapters

TOOLS REQUIRED

Soft Pry Tool Phillips Head Screw Driver 18mm Socket Socket Wrench





STEP 1

Remove the (6) plastic push pins holding the factory splash shield onto the vehicle.



STEP 2

Locate the factory fog lights. Disconnect the wiring harness from the lights by depressing the tab on the light's connector. Pull the connector away from the light. Loosen and remove the (8) 18mm nuts securing the bumper to the vehicle.





STEP 3

Using a Phillips head screw driver, remove the (4) screws securing each light to the vehicle.



STEP 4

Secure the fog light assembly to the bumper using the original mounting hardware. Once secured, plug the provided wiring harness adapter to each fog light. Re-install the bumper to the vehicle following steps 1-2 in reverse order. Plug in each fog light to the vehicle wiring harness.

Installation is now complete.