



DOOR PANEL STORAGE ORGANIZER TRAY

(2011-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Door Tray
(1) RH Door Tray

TOOLS REQUIRED

Soft Pry Tool

SKU # J171698

STEP 1



Identify the install location of the door trays. The tabs on the tray press in behind the factory door panel.

STEP 2



Peel off the tape backing on the mounting tabs. Begin by pressing the forward most tabs (1) behind the panel. Then, press in the bottom tabs (2), followed by the rear most tabs (3).



STEP 3

Repeat steps 1-2 to the opposite side of the vehicle.

Installation is now complete.