



MESH TOP

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Mesh Top
- (1) 3" Elastic Band
- (6) 5" Elastic Bands
- (4) 8" Elastic Bands

TOOLS REQUIRED

N/A

SKU # J174545

STEP 1



Remove the OEM vehicle top following OEM specified remove steps.

STEP 2



Identify the front of the mesh top by locating the (1) center grommet.

STEP 3



Drape the front of the mesh top over the vehicle center roll bar. Secure the front of the mesh top to the windshield channel using (1) 3" elastic band.

STEP 4



Secure the sides of the mesh top to the roll bar using (6) 5" elastic bands and (4) 8" elastic bands.

Installation is now complete.