



PRECISION MOLDED FLOOR LINERS

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Front Floor Liner
(1) RH Front Floor Liner

TOOLS REQUIRED

Vacuum Cleaner

SKU # J177057



STEP 1



Remove any existing floor mat from the vehicle. Clean the vehicle carpet using a vacuum cleaner.

STEP 2



Align the floor liner to the vehicle floor and press into place. If applicable, align the vehicle floor hooks into the floor liner mounting holes.

Repeat steps 1-2 for the remaining vehicle floor liners. Installation is now complete.