

HD SLIM REAR BUMPER

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Rear Bumper
- (2) Rear Bumper Mounting Plates
- (1) Spare Tire Relocation Bracket
- (2) 3/4" D-Rings
- (2) D-Ring Isolators
- (4) M12x1.75 x 40mm Bolts
- (4) M12 Lock Washers
- (4) M12 Flat Washers
- (3) 1/2-20 x 1.75" Bolts
- (6) 1/2 Flat Washers
- (3) 1/2-20 Lock Nuts
- (1) 4mm Allen Key
- (2) M8 x 25mm Allen Bolts
- (4) M8 Flat Washers
- (2) M8 Lock Nuts
- (2) M8 Lock Washers
- (1) 5mm Allen Key

TOOLS REQUIRED

13mm, 16mm, 18mm, 19mm Sockets/ Wrenches Ratchet

SKU # J180716





Remove the spare tire from the vehicle by removing the (3) lug nuts.



STEP 2

STEP 1

Remove (2) 16mm bolts from each side of the rear bumper. Once removed, pull the bumper away from the vehicle.

Jeep



STEP 3

Insert (1) bumper mounting stud plate into the vehicle frame rail, allowing the (2) nuts to show through the pre-drilled holes in the frame.

Repeat this step for the opposite side of the vehicle.



STEP 4

With assistance, align the bumper to the vehicle pre-drilled holes, and secure the bumper to the vehicle using (2) M12 x 40mm bolts, (2) M12 lock washers, and (2) M12 flat washers per side.

Adjust the bumper as necessary for best fit, and tighten all hardware evenly until the bumper is secure.





STEP 5

Thread (3) $1/2-20 \times 1.75$ " bolts with (3) 1/2 flat washers into the threaded holes in the spare tire relocation bracket, and tighten into place.



STEP 6

Secure the spare tire relocation bracket to the vehicle tire carrier using (3) 1/2 flat washers and (3) 1/2-20 lock nuts. Tighten all hardware evenly until secure.

Jeep



STEP 7 (AUX LIGHTS)

Remove the mesh covers if desired. Mount optional LED lights to the LED lighting mounts on the inside of the bumper using the included M8 bolts, lock washers, washers, and nuts.



STEP 8

Install the spare tire onto the vehicle tire carrier using the original (3) lug nuts. Install the (2) 3/4" D-Rings to the bumper.

Installation is now complete.