



HEADER PANEL FOR REDROCK TOPS

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Header Panel

TOOLS REQUIRED

13mm Wrench

SKU # J181078

STEP 1



Remove the vehicle top. Remove any existing header panel.

Loosen the (2) 13mm bolts to allow the mounting brackets to be free from the header. Fit each bracket into the slot in the vehicle

STEP 2



While pressing the header panel towards the front of the vehicle, evenly tighten the (2) 13mm bolts to secure the header to the vehicle.



STEP 3

With the header installed, the vehicle is now compatible with REDROCK tops utilizing the fold-over front edge (SKUs: J181076 & J181077) . The plastic lip on the top will fold over and lock into the header. To utilize the rounded edges of the header, insert the top plastic lip, and slide the lip into the edge.

Installation is now complete.