



# STEERING STABILIZER

(1997-2006 WRANGLER TJ)  
(2007-2018 WRANGLER JK)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) Steering Stabilizer
- (2) Bushing Sleeves

### TOOLS REQUIRED

---

- 18mm Socket/Wrench
- Ratchet
- Spray Lubricant
- Hammer
- Flathead Screwdriver

**STEP 1**



Locate the original steering stabilizer attached to the vehicle axle and steering linkage. Remove (1) 18mm bolt from the axle housing.

Note: The nut has a flag attached to prevent spinning while loosening the bolt. The bolt and flag nut will be reused during assembly.

**STEP 2**



Remove (1) 18mm nut securing the steering stabilizer to the steering linkage mounting stud.

Note: The mounting nut will be reused during assembly.



**STEP 3**

Hinge the steering stabilizer downwards, and slide the off of the mounting stud. Remove the steering stabilizer from the vehicle.



**STEP 4**

Place the new steering stabilizer on a workable surface. Spray the inside of the steering stabilizer bushing, and the bushing sleeve with lubricant. Gently hammer the bushing sleeve into the bushing.

Repeat this step for the remaining bushing/sleeve.



**STEP 5**

Compress the new steering stabilizer to approximately the same size as the original steering stabilizer.



**STEP 6**

Fit the new steering stabilizer into the vehicle. Secure the steering stabilizer into place using the original hardware, and tighten to specification, see below. Installation is now complete.

**Axle Housing Bolt/Flag Nut:** 50 ft./lbs.

**Steering Bracket Nut:** 50 ft./lbs.