



FOG LIGHT SURROUND

(2018-2023 WRANGLER JL - EXCLUDING 4XE)
(2020-2023 GLADIATOR JT)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Fog Light Surround

TOOLS REQUIRED

Panel Removal Tool
7mm Socket
Ratchet

STEP 1



Remove (7) plastic push clips from the vehicle bumper end cap panel.

Note: The push clips may vary in location depending on vehicle trim level.

STEP 2



With the end cap removed, remove (1) 7mm screw from the back of the fog light surround trim.



STEP 3

From the front of the bumper, use a pry tool to disconnect the mounting clips attached to the trim panel. Use the new trim panel as a template to locate the clips on the original part. Pull the trim panel away from the vehicle.



STEP 4

With the original panel removed, press the new trim panel into place. Ensure all mounting clips are properly aligned, then press firmly to engage the clips. Use the original (1) 7mm screw to secure the trim into place. Re-install the bumper end cap panel using OEM hardware.

Installation is now complete.