

VISION LED FOG LIGHTS

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) LED Fog Lights
(2) Wiring Harness Adapters
(2) Wire Leads

TOOLS REQUIRED

Soft Pry Tool
Phillips Head Screw Driver
18mm Socket
Socket Wrench
Wire Cutters
Multi Meter or Test Light

STEP 1



Remove the (6) plastic push pins holding the factory splash shield onto the vehicle.

STEP 2



Locate the factory fog lights. Disconnect the wiring harness from the lights by depressing the tab on the light's connector. Pull the connector away from the light. Loosen and remove the (8) 18mm nuts securing the bumper to the vehicle. Remove the bumper from the vehicle.



STEP 3

Using a Phillips head screw driver, remove the (4) screws securing each light to the vehicle.



STEP 4

Secure the fog light assembly to the bumper using the original mounting hardware. Once secured, plug the provided wiring harness adapter and wire lead extension into the fog light.

Re-install the bumper to the vehicle reusing the original 18mm nuts.



STEP 5

Plug the fog light into the vehicle fog light wiring harness. Splice the additional (1) Yellow wire lead to the vehicle parking light wiring in the fender flare (White/Green 12v+ wire).



STEP 6

Installation is now complete.